



## Support Forum

[Post Your Message](#)

[Subscribe](#)

[\[View All\]](#)

Archiv:

[Select...](#)

Search

### Use customer's material

I have nearly completed a design for two blank panels which I have. How do I send these two blank panels to you so that they can be connected with the Front Panel Express design I create for them? Do I send the panels with a CD copy of my FPD files?

Thank you! :D

Posted By: Brian H on Jul 25, 2008 05:30AM Category: Ordering

[Reply](#) | [View Replies \[1\]](#)

### Bending

Is it possible for a small panel to be bent so that I could order end panels for a small enclosure that provide a right angle mounting tab?

Posted By: Michael Evinger on Jun 12, 2008 08:04PM Category: Production

[Reply](#) | [View Replies \[1\]](#)

### Object properties shows millimeters and inches

In the version 3.5 software, why does the "Object Properties" dialog display X and Y in inches even when the rest of the units (such as height and width) are shown in millimeters? this makes designing a lot more work than it needs to be as I have to constantly convert units back and forth using a calculator.

Thanks,

PeterM

Posted By: Peter Montgomery on Apr 10, 2008 08:34AM Category: Front Panel Designer

[Reply](#) | [View Replies \[1\]](#)

### User settings not stored by software?

Is the ability to choose millimeters or inches as the standard measuring unit working in the version 3.5 software? Every time I go into Edit->Settings, I choose "millimeter" from the "Grid Distance X" dropdown box, click "Set as Default" and then hit "OK". When I open the settings dialog again, everything is back to inches. I looked in the registry for where the program would store these settings, but only found entries for the positions of the various dialogs and windows. Are these settings actually being stored somewhere?

Thanks,

PeterM

Posted By: Peter Montgomery on Apr 10, 2008 08:31AM Category: Front Panel Designer

[Reply](#) | [View Replies \[1\]](#)

### PayPal Payment?

Hello,

I have a front panel designed and was wondering do you accept PayPal as a form of payment. I don't have a credit-card and would prefer to use the USPS for shipping as UPS to Australia gets pretty expensive and I have had loads of stuff sent via USPS with no problems.

Regards,

Robert Heffernan

Albury, Australia

Posted By: Robert Heffernan on Apr 05, 2008 01:57AM Category: Ordering

[Reply](#) | [View Replies \[3\]](#)

### Can I set the point where a threaded thru-hole starts being threaded ?

Hello,

I would like to know if it's possible within fpd to set the place at which the threading in a threaded thru-hole begins.

As you can see the reason for this is that with standard thread orientation my XLR socket when fully screwed in is 125 degrees out of alignment. I am using a Vista OS so don't have access to the front panel designer help files.

any help appreciated :)

Posted By: Douglas Hunter on Mar 13, 2008 12:49PM Category: Front Panel Designer

[Reply](#) | [View Replies \[2\]](#)

< [Prev](#)   [1](#)   [2](#)   [3](#)   [4](#)   [5](#)   [6](#)   [7](#)   [8](#)   [9](#)   [10](#)   [11](#)   [12](#)   [13](#)   [14](#)   [15](#)   [16](#)   [17](#)   [18](#)   [Next](#) >  
[19](#)   [20](#)   [21](#)   [22](#)   [23](#)   [24](#)   [25](#)   [26](#)   [27](#)   [28](#)   [29](#)   [30](#)   [31](#)   [32](#)   [33](#)   [34](#)   [35](#)   [36](#)   >  
[37](#)   [38](#)   [39](#)   [40](#)   [41](#)   [42](#)   [43](#)   [44](#)   [45](#)   [46](#)   [47](#)   [48](#)   [49](#)   [50](#)   [51](#)   [52](#)   [53](#)   [54](#)  
[55](#)   [56](#)   [57](#)   [58](#)   [59](#)   [60](#)   [61](#)   [62](#)   [63](#)   [64](#)   [65](#)   [66](#)   [67](#)   [68](#)   [69](#)   [70](#)   [71](#)   [72](#)  
[73](#)   [74](#)   [75](#)   [76](#)   [77](#)   **78**   [79](#)   [80](#)

**Please enter your message:**

\* = required field

Your Name\*

Your Email\*

Subject\*

Message\*

Select Category\*

Select category...

Attached file:

No file selected

Please enter here the word as displayed in the picture in **REVERSE** order. This is to prevent spamming.\*



If you can't read the word, [click here](#).

Receive any replies by email?

**Post Message**